


USA Cloth Goal Creases

VERY IMPORTANT: DO NOT lay crease on wet ice, as it will adhere instantly.

Instructions:

1. Lay crease down in crease area.
2. Trim to fit, if necessary.
3. Wet the centre of the crease with warm water, this will hold it down. Then proceed to roll the crease with water from the centre outward with a paint roller.



Manufactured and Designed in Canada by
Big Hill Services Ltd.
1-888-932-2728 or (403) 932-3598